

PURPOSE

Use this kit for adjustment of maximum water temperature.

TO ADJUST MAXIMUM TEMPERATURE:

NOTE: Prior to adjustment, make sure the handle is in the maximum hot position.

Remove the handle and bonnet. Turn on the water to its maximum temperature by pushing the valve stem up and turning clockwise.

WARNING: Risk of personal injury or product damage. The indexer and top disc are required for proper temperature limit stop function.

Mark the current position of the temperature stop tab (top edge) on the mounting nut with a marker or pencil. Lift both the indexer and the top disc just enough to clear the splines and to allow rotation.

NOTE: Each spline notch is an average 9.5 degree F. change in temperature.

Turn the indexer, top disc, and valve stem counterclockwise until the desired temperature is achieved. When desired temperature is achieved, reinstall indexer and top disc onto valve, making sure top disc is snapped fully into the indexer.

Turn off water by pulling valve stem down. Reinstall the bonnet and handle.

