





23486IN-4ND-**
WALL MOUNT SC LAV FAUCET

ROUGH-IN DIMENSIONS (in mm)



23486IN-4ND-**


PRESSURE AND HOT INLET TEMPERATURE



P (BAR)





$0.5 < 3 < 5.5$




T (°C) <65

TOOLS REQUIRED




INSTALLATION INSTRUCTIONS


1




2




3




4




5



6



AERATOR CLEANING AND SERVICING




Ensure there is no leakage from the sides of aerator after tightening.

CLEANING INSTRUCTIONS



SERVICE PARTS



**Finish code must be specified when ordering.