












KALLISTA®

Installation Guide



<p>Record your model number.</p>	<p>Important Information For new installations, assemble the faucet to the sink before installing the sink. Follow all local plumbing and building codes.</p>	<p>1 Install the O-ring into the groove on the bottom of the spout. Insert the spout.</p> 	<p>2 Partially thread the screws as shown.</p> 	<p>3 Loosely fasten the spout with the washers and threaded spout ring.</p> 	<p>4 Position the screws to the front and back. Tighten the screws.</p> 
<p>5 Connect and tighten the supply hoses. Do not kink the hoses!</p>  <p>Ø 3" (76 mm) Min</p>	<p>6 Turn on the water supplies and check for leaks.</p> 	<p>7 Use the key to remove the aerator.</p> 	<p>8 Run water through the faucet to flush any debris.</p> 	<p>9 Use the key to reinstall the aerator.</p> 	

Questions? Problems? For additional assistance, please contact KALLISTA's Customer Service Department at 1-888-4-KALLISTA (1-888-452-5547) or kallista.com.