

CUSTOMER CARE

KOHLER India's Faucets* used in normal residential settings are warranted to be free of defects in material and workmanship for seven years from date of purchase. KOHLER India's Faucets* used in commercial settings are warranted to be free of defects in material and workmanship for five years from date of purchase. If, in the opinion of Kohler India, the defect is due to defects in material or workmanship, Kohler India will, for a period of 7 (seven) years, for faucets used in residential settings, and for 5 (five) years, for faucets used in commercial settings, from the date of sale of the Faucet to the original purchaser ("warranty period"), at its sole option, repair or replace free of cost, any defective component or part of the Faucet, subject to the terms and conditions described below:

1. Kohler India or its Authorized Service Franchisee alone can service/repair the Faucet.
2. Proof of purchase (original sales receipt) must be provided with all warranty claims or requests.
3. The service/repair of the warranty shall be provided only within the municipal limits of the town or city where the branch office of Kohler India or Authorized Service Franchisee is located.

To obtain warranty service, please contact:

India Customer Service Centre
Kohler India Corporation Pvt. Ltd.,
4th Floor, Paras Downtown Center,
Golf Course Road, Sector 53,
Gurgaon-122002
Haryana, India
www.kohler.co.in

4. If the Faucet is installed beyond the municipal limits of Kohler India's branch office/Authorized Service Franchisee locations, any and all costs and expenses incurred for repair/service of the Faucet in respect of a) to and from travel of service personnel b) transportation of the Faucet and/or spare parts and/or components from the location of Kohler India's branch office or Authorized Service Franchisee to customer's location and back shall be borne wholly and solely by the customer at the prevailing rates, and Kohler India shall not be liable for any damage caused to the Faucet in transit or delivery for repair.
5. This warranty shall automatically terminate upon the expiry of the warranty period even if the Faucet has not been installed after purchase or has not been in use for any part or whole of the warranty period for any reason whatsoever.

*Trend™ faucets; MasterShower™ tower; BodySpa™ systems and components; WaterHaven™ tower, systems and components; Polished Gold finishes; fittings; all recommended fixture plumbing accessories, including but not limited to, grip rails, trim kits, drains; Duostrainer® sink strainers and soap/lotion dispensers; are warranted to the original purchaser to be free of defects in material and workmanship for one year from date of purchase. All other aspects and conditions of the above stated warranty, other than duration, apply to these faucets.

**Never use cleaners containing abrasive cleansers, ammonia, bleach, acids, waxes, alcohol, solvents or other products not recommended for chrome. This will void the warranty.

6. This warranty remains applicable only if the Faucet has at all times been used strictly in accordance with the terms of this warranty and has not been improperly or negligently handled. This warranty does not cover problems arising from insufficient water pressure, excessive water impurities or improper care and cleaning**. Kohler is not responsible for labor charges, installation or other incidental or consequential costs. In no event shall the liability of Kohler India exceed the purchase price of the Faucet. Improper care and cleaning will void the warranty.
7. In the event of any repairs/replacement of any parts of the Faucet, this warranty shall thereafter continue and remain in force only for the unexpired period of the warranty. Any time consumed for the repair/ replacement of parts including transit of the Faucet or its parts or any period during which the Faucet has not been used whether under warranty or otherwise shall not be excluded from the warranty period.
8. In the event of non availability of components or parts due to any reason whatsoever neither Kohler India nor its Authorized Service Center nor the Dealer will be responsible or liable for any delay that may be caused to service/repair of the Faucet.


This is Kohler India's exclusive written warranty.

Care and cleaning guidelines for chrome and Vibrant® PVD colors/finishes

- Do not use cleaners containing ammonia, bleach, or acid.
- Use a mild detergent (such as dishwashing soap). Do not use abrasive cleaners.
- Rinse and be sure to wipe the entire surface dry.

The ideal cleaning technique is to always blot dry any water from metal surfaces. Allowing water to evaporate on metal will form water deposits. It is important to use a dabbing action to dry metal, not an abrasive or rubbing action. Cleaning with a damp sponge and buff drying should keep your faucet looking beautiful.

KOHLER®



Bottle Trap and Extension Installation and User Guide


MODEL NUMBERS

16407IN

Important! Please quote the above model number(s) when ordering spares

IMPORTANT
INSTALLER: THIS MANUAL IS THE PROPERTY OF THE
CUSTOMER AND MUST BE RETAINED WITH THE PRODUCT
FOR MAINTENANCE AND OPERATIONAL PURPOSES.

DIMENSIONS



All dimensions in mm

SPECIFICATION

Plumbing Connections

For connection to 1 1/4" diameter pipework.

USER MAINTENANCE

Cleaning

Caution! Risk of product damage.

Many cleaners contain abrasive and chemical substances, and should not be used for cleaning stainless steel, enamel, plated or plastic fittings.

These finishes should be cleaned using a mild washing up detergent or soap solution, rinsed and then wiped dry with a soft clean cloth.


INSTALLATION

Before you Begin

1. Make sure that the bottle trap is installed by a competent installer.
2. Turn off the water supply.
3. The plumbing installation must comply with Building Regulations or any particular regulations and practices, specified by the local water company or water undertakers.
4. Before installation carefully inspect the item for any signs of damage.

1074205-IN2-A

Install the Bottle Trap and Extension



1. Fit the washer to the end of the bottle trap, and screw the bottle trap into the main body.
2. Fit a nut onto the wider end of the plastic pipe.
3. Fit a nut onto the wider end of the adjustable inlet, then insert the inlet into the plastic pipe.
4. Insert the plastic pipe into the bottle trap and hand tighten the nut to secure in position.
5. Fit the flat washer onto the top of the nut on the adjustable inlet, and screw the assembly onto the bottom of the basin, making sure all connections are tight.
6. Measure the distance from the main body to the waste outlet in the wall.
7. If the extension pipe needs to be cut to fit, then do this now.
8. Fit a nut to one end of the extension pipe then fit the conical washer onto the nut, tapered end first. Screw the extension pipe securely into the main body.
9. Attach the wall flange to the other end of the extension pipe, and secure this end to the waste pipe using a suitable connector. Tighten securely.

Finish the Installation

1. Make sure that all the connections are tight.
2. Check for any leaks.