








**订购时请说明颜色编号
**Color code must be specified when ordering

39734T-9 恒温三出水淋浴柱 OL	
安装之前	BEFORE YOU BEGIN
所有的资料是按最新出版的产品资料编写而成。科勒公司保留任何时候不经通知即可改变产品特性、包装或产品可供类型的权利。 说明书包括重要的安装、保养及清洁方面的内容，请把这些资料交给用户阅读。	All information is based on the latest product information available at the time of publication. Kohler Co. reserves the right to make changes in product characteristics, packaging, or availability at any time without notice. Please leave these instructions for the consumer. They contain important information.
工具和材料(自备)	TOOLS AND MATERIALS(NOT INCLUDED)
 活动扳手 Adjustable Wrench  水平尺 Level  电钻 Drill  铅笔 Pencil  螺丝刀 Screwdrivers  密封带 Sealant Tape	
使用环境	OPERATION CONDITION
1. 推荐冷热供水压力：0.2MPa~0.4MPa(2bar~4bar)，水压过低可能会影响淋浴体验。 2. 如果供水压力大于0.5MPa(5bar)，安装减压阀。 3. 热供水温度最低：50℃；最高：80℃。 4. 推荐的热供水温度：65℃。 5. 温度的设定基本范围为：20℃到49℃。 6. 安全限位温度：37℃。 7. 最高混合温度：49℃。 8. 花洒最高工作温度及环境温度：60℃。请特别注意花洒同花洒连接的臂管须远离浴霸，否则可能损坏花洒及其密封件，甚至对使用者造成伤害。 9. 使用环境温度0℃以上。如果等于或低于0℃，请关闭水表阀门，并排空产品内的水，以防止可能因水结冰而产生的零件变形、产品冻裂等现象。	1. Recommended supply pressures: 0.2MPa~0.4MPa (2bar~4bar) on hot and cold water. Low water pressure may affect shower experience. 2. Supply pressure greater than 0.5MPa(5bar): install a pressure reducer. 3. Hot water temperatures, minimum: 50℃, maximum: 80℃. 4. Recommended hot water temperature: 65℃ (energy-saving). 5. Setting range, approximately: 20℃ to 49℃. 6. Safety stop at: 37℃. 7. Maximum mixed water temperature: 49℃. 8. The highest environment temperature for handshower & showerhead is 60℃. Please keep handshower, showerhead and shower arm away from heater, or it may become damaged and cause injury to the user. 9. Maintain the operating temperature above 0℃. If the temperature is at or below 0℃, close the water meter valve and drain the water from the product to prevent deformation or cracking caused by freezing.

重要信息

产品符合IPX5防水等级。

注意！ 请勿在本产品安装之后再做供水管路水压测试。

注意！ 首次使用时可能电池没有电，需先试用，如没有电，请按照电池安装步骤更换电池。

注意！ 若产品长期不使用，请取出电池，安放在安全位置，待重新使用时，重新安装电池使用。

注意！ 器具不打算由存在肢体、感官或精神能力缺陷或缺少使用经验和知识的人（包括儿童）使用，除非有负责他们安全的人对他们进行与器具使用有关的监督或指导。

注意！ 应照看好儿童，确保他们不玩耍本器具。

警告！电池使用注意事项：

⚠ 切勿使用不合格的电池。

⚠ 不可短路、挤压与碰撞。

⚠ 切勿拆开或置于火中，避免放置于过热(超过60°C)、潮湿或腐蚀性环境中。

⚠ 不可让电池电极与金属品接触，导致短路。

⚠ 电池浸水后禁止使用。

IMPORTANT INFORMATION

These products are rated to IPX5.

NOTE! Do not apply water pressure test on water supply pipes after completing the product installation.

NOTE! Battery may be no electricity for the first time, Test the product first. If there is no power, replace it according to the installation steps.

NOTE! If the product will not be used for a long time, remove the battery and store it in a safe place. Reinstall the battery when using the product again.

NOTE! This appliance is not intended for use by persons with physical, sensory, or mental limitations, or by those lacking experience or knowledge (including children), unless they are supervised or instructed on the safe use of the appliance by a person responsible for their safety.

NOTE! Supervise children to ensure they do not play with the appliance.

WARNING! For battery.

⚠ Do not use unqualified battery.


⚠ No short circuit, extrusion and collision.

⚠ Do not expose battery to heat source or install in any location where the temperature may exceed 60°C. Keep away from moisture or corrosion.

⚠ Battery electrodes must not be contacted with metal objects, resulting in short circuit.

⚠ Do not use battery after immersion.

使用说明



慢慢旋转温控把手即右把手，调整温度，安全限位温度为37°C；如想得到更高温度，按住按钮继续逆时针旋转。

1. 出水模式是通过开关按键来控制。按压本体上任意开关按键，相应功能开启和关闭。

2. 打开任意出水模式，玻璃面板数显区域显示实时温度。

3. 若灯光微弱或闪烁，则电池电压不足，请参照“安装和更换电池”步骤，更换电池。

4. 所有开关按键处于关闭状态时，不显示温度也不亮灯。

开关按键图标说明

Icon description of switch button



浴缸出水口
Bath spout



头顶花洒雨淋水
Katalyst rain



手持花洒
Handshower

The temperature is set by slowly turning the temperature selector(right-hand handle). For safety reasons, there is a stop that limits temperature to 37°C. To get a higher temperature, push the button and continue turning the temperature selector counter-clockwise.

1. Water dispense is set by switch buttons. Press any switch button on the faucet body to turn the corresponding function on or off.

2. Turn on any water mode. The digital display on the glass panel will show the real-time temperature.

3. If the light is dim or flickering, the battery voltage is low. Replace the battery according to the steps in “Install & Replace Battery”.

4. When all switch buttons are off, the temperature display and indicator light remain off.

1665906-T2-B

2

有害物质统计表

Statistics of Contents of Toxic or Hazardous Substances or Elements

部件名称 Part Name	有害物质名称 Toxic or Hazardous Substance or Elements									
	铅	汞	镉	六价铬	多溴联苯	多溴二苯醚	邻苯二甲酸二正丁酯	邻苯二甲酸二异丁酯	邻苯二甲酸丁苄酯	邻苯二甲酸二(2-乙基)己酯
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr(VI))	Polybrominated Biphenyls (PBBs)	Polybrominated Diphenyl Ethers (PBDEs)	Dibutyl Phthalate (DBP)	Diisobutyl Phthalate (DIBP)	Butyl Benzyl Phthalate (BBP)	Bis(2-Ethylhexyl) Phthalate (DEHP)
淋浴柱组件 Column kit	×	○	×	○	○	○	○	○	○	○
龙头BOX组件 Faucet BOX kit	×	○	×	○	○	○	○	○	○	○
数显模组及霍尔开关组件 Digital display module & hall switch kit	○	○	○	○	○	○	○	○	○	○
电池及充电线组件 Battery & charging cable kit	○	○	○	○	○	○	○	○	○	○
温度传感器组件 Temperature sensor kit	○	○	○	○	○	○	○	○	○	○

○：表示该有害物质在该部件所有均质材料中的含量均不超出电器电子产品有害物质限制使用国家标准要求。

×

表示该有害物质至少在该部件的某一均质材料中的含量超出电器电子产品有害物质限制使用国家标准要求。

以上未列出的部件，表明其有害物质含量均不超出电器电子产品有害物质限制使用国家标准要求。

注：本表格提供的信息是基于供应商提供的数据及科勒公司的检测结果。

本产品应用环保设计理念，在当前技术水平下，所有有害物质的使用已经控制到了最低程度，科勒公司会继续努力通过改善现有技术来减少这些物质的使用。

10

本产品的“环保使用期限”为10年，科勒公司根据产品设计特性指定该期限。只有在本产品使用说明书所述的正常情况下使用本产品时，“环保使用期限”才有效。

○：Indicates that the homogeneous substance in the material composition is below the high limits of the current national standard.

×

Indicates that at least one of the homogeneous substance in the material composition exceeds the high limits of the current requirements. Components not listed above, indicates that the homogeneous substance in the material composition is below the high limits of the current national standard.

Note: the information provided is based on the supplier data and Kohler inspection results. The product is designed not to hurt the environment. Under current technology, all hazardous materials have been used in the smallest amounts possible. Kohler will strive to reduce the use of these hazardous materials used in this product.

10

The product “service life for environment protection” is 10 years; Kohler Company will specify product service life based on product characteristics. The product “service life for environment protection” is only effective when the product is used as described in the product specification.

清洗说明

CLEANING INSTRUCTIONS

适用于所有加工处理过的表面：以中性肥皂水清洗镀层表面，再以干净的软布彻底擦干整个表面，许多清洁剂，比如氨水、去污粉及洁厕灵等，会对电镀表面造成伤害，切忌使用。

有磨损性的清洁用具或清洁剂也不可使用时科勒牌的水龙头及其配件上。

All Finishes: Clean the finish with mild soap and warm water. Wipe entire surface completely dry with clean soft cloth. Many cleaners may contain chemicals, such as ammonia, chlorine, toilet cleaner etc. which could adversely affect the finish and are not recommended for cleaning.

Do not use abrasive cleaners or solvents on Kohler faucets and fittings.

1665906-T2-B


7

安装和更换电池

从本体底部左侧将电池盒盖向左抽出，取下电池盒盖，电池盒会掉出来。

捏着电池盒上盖的两个卡扣，打开电池盒，按照电池盒上的正负极指示，安装四节5号电池。然后依次装回电池盒。

打开龙头试水，如温度显示正常，表明正确更换电池完成。



INSTALL & REPLACE BATTERY

Slide the battery box cover to the left from the lower-left side of the body. Remove the cover, the battery box will drop out automatically.

Press the two lclips on the top of the battery box and open the battery box. Follow the polarity marks on the battery box and install four AA batteries. Reassemble the battery box and slide it back into place.


Turn on the faucet to check water flow. If the temperature display functions normally, the battery replacement is complete.

维护与保养

如何清洗滤网

滤网可起到保护龙头的作用，但长时间使用后，水垢或杂质可能会堵塞滤网，降低水流量。如果有类似情况发生，关闭水源，卸下淋浴柱。

用2.5mm六角扳手(3)旋出两个紧固螺钉(4)，卸下龙头。用热醋清洗接头(2)滤网。然后依次装回。



CARE AND MAINTENANCE

How to Clear the Filter

The filters can protect the faucet, but it may get obstructed and reduce water flow after a long time of use. If this happens, turn off the water supply, uninstall the shower column.

Unscrew two screws(4) with 2.5mm hex wrench (3) to uninstall the faucet. Clean the filters by soaking them in warm vinegar. Reinstall them in turn.

如何清洗温控阀

如果供水的水质较硬或长时间使用，水垢或杂质会阻塞温控阀上的滤网，流量会降低。需要清理请按照下列步骤进行：


关闭供水系统，使流量阀处于打开位置后进行温控阀的拆卸作业。温控阀是较敏感的配件，要十分小心。确保温控把手按钮垂直朝下(此时对应37°C)。依次拆卸温控把手组件。

取出恒温阀阀芯。然后进行清洗。

把清洗后的恒温阀装回水道本体内，注意要对好定位孔和定位环。装入水道本体，然后锁紧压紧螺母。依次安装把手组件。

注意： 确保拆卸、安装过程中不要转动温控阀轴。如不小心转动了阀轴，要调整阀轴使外齿上的划线标识与相邻的塑料套上的凹槽对齐，或者按前述方法进行调整。

此时按钮应是垂直朝下(此时对应37°C)。



How to Clear the Thermostatic Cartridge

Very hard water can obstruct filters on the thermostatic cartridge and reduce the water flow. Please clean the cartridge as follows:

Shut off the water supply of the faucet and turn on the water flow valve, then proceed to emove the cartridge. The cartridge is sensitive part, please be careful. Make sure the button on the temperature handle is downward vertically(It is 37°C at this position). Uninstall the temperature handle assembly in turn.

Remove the thermostatic cartridge. Then clean it.




Reinstall the thermostatic cartridge into the valve body. Ensure the stop hole and stop ring are properly aligned. Insert the cartridge into the valve body, then tighten the nut. Install the handle assembly in sequence.

NOTE: Do not turn the cartridge when reinstalling it. If you turn it accidentally, you should adjust it and be sure that the line mark is correctly in line with the groove, or readjust as per the steps of verification and setting.

Make sure the button on the temperature handle is downward vertically(It is 37°C at this position)

安装尺寸

ROUGH-IN DIMENSIONS



安装步骤

如何安装水龙头

为使安装顺利，G1/2"内螺纹管道配件(1)应已安装好，预留150mm的间距，保持水平，并垂直于装修好的平整墙面。彻底冲洗供水管，以清除管路中的杂质。



注意：请在安装进水接头(2)之前做供水管路水压测试。

在螺纹上缠绕足以密封的密封胶带或涂适合的密封胶，安装两个进水接头(2)到冷热供水管上。

使用水平尺(包装自带)调节两个进水接头，使其中心距离为150mm并保持同一水平。它们凸出墙面的尺寸应该在35~44mm之间。

用2.5mm六角扳手(3，包装自带)调整两个紧固螺钉(4)，将龙头本体插入两个进水接头，使本体贴紧墙面，用水平尺(5，用户自备)保证本体上表面水平。

用2.5mm六角扳手锁紧两个紧固螺钉。



INSTALLATION

How to Install the Faucet

To perform installation, installer must provide G1/2" female supply fittings(1), spaced 150mm apart and horizontally. The supply fittings should be vertical the finished wall. Flush the water supply pipes thoroughly to remove debris.

NOTE: Apply water pressure test on water supply pipes before installing the connectors(2).

Apply enough tape or suitable sealant on threads. Install two offset connectors(2) into the hot and cold supply pipes.

Use the level(included in the package) to adjust the center-to-center distance between the connectors to 150mm horizontally. They should extend 35 to 44mm beyond the finished wall.

Adjust two screws(4) with 5mm hex wrench (3, included in the package). Install the faucet body to the connectors until it is against the finished wall. Ensure the upper surface of the faucet body is horizontal with the level(5, not provided).

Tighten two screws with 2.5mm hex wrench.

How to Install the Shower Column and Handshower

Rehearse the shower column installation for the hole location determination.


1. Slide the plug(6) onto the connecting pipe(8) and press it firmly against the top surface of the body. Insert the shower column onto the connecting pipe and compress the plug. Verify the shower column is fully seated.
2. Make sure the shower column is vertical. Check whether it is vertical with the level(5). Mark the hole positions on the wall with a pencil to determine the drilling locations.

Install the shower column.

1. Drill Ø8mm holes(The depth is not less than 35mm) on the marks. Insert the anchors(9) into the holes.
2. Insert the shower column onto the connecting pipe(8) firmly to the end.
3. Tighten the screws(10) with a screwdriver in order to secure the shower column.
4. Tighten the tube(12) onto the shower column using screws(11).

Install the Handshower

1. Put the screen washers(13) into the hoses(14). Connect the connector(15) and handshower(15) with hose. **NTOE:** Do not overtighten.
2. Put the check valve(17) into the handshower if needed.
3. Hang the handshower on the bracket(18).



如何安装花洒淋浴柱和手持花洒

试装淋浴柱，以确定打孔位置。

1.将软垫(6)穿过连接头(8)使其贴紧本体上表面。将淋浴柱插入本体连接头并压紧软垫，确保淋浴柱插到底。

2.用水平尺(5)检查淋浴柱的垂直度，接着用铅笔在墙上标记孔位，以确定打孔位置。

安装淋浴柱组件

1.在墙上标记处钻Ø8mm且深度最小为35mm的孔。将胀塞(9)放入孔中。

2.将淋浴柱插入本体连接头(8)，需要插到底。

3.用十字螺丝刀锁紧螺钉(10)以固定淋浴柱。

4.用螺钉(11)将弯管(12)拧紧到淋浴柱上

安装手持花洒

1.将滤网垫片(13)放入花洒软管(14)接头内，用软管连接手持花洒(15)与本体底部接头(15)。**注意：**不要过分拧紧。

2.根据需要将单向阀(17)放入到花洒进水端。


3.将花洒挂在花洒挂架(18)上。

如何安装头顶花洒

安装头顶花洒(19)前，切换至头顶花洒出水状态，打开冷热水源冲掉管路中杂质。

根据需要安装限流器(20)。先取出垫片(21)，按图示方向放入限流器，再装回垫片。

将头顶花洒旋到弯管(12)出水口上，用带状扳手锁紧。



How to Install the Showerhead

Ensure it is in the position for showerhead(19). Flush hot and cold water supplies to remove any debris before the showerhead is installed.

Before installation, put the regulator(20) into the showerhead if needed. Take out the washer(21) and install the regulator as shown, reinstall the washer.

Tighten the showerhead onto the tube(12) outlet with strap wrench.


安装结果检查

1.接干电池。打开电池盒盖，观察是否已安装有4节5号(AA号)干电池，如没有干电池，请参考“安装和更换电池”步骤，装入电池。

2.检查并确保所有衔接处都已拧紧，确保开关按键未开启。打开水源，使其流入阀芯。检查所有连接处是否漏水，根据需要修理之。

3.产品试水。打开各路开关，检查功能是否正常，温度显示是否正常等。检查各个衔接处连接是否良好，观察出水效果是否正常。

开关阀复位，关闭龙头。



INSTALLATION CHECKOUT

1. Connect the batteries
Open the battery box cover and check whether four AA batteries are installed. If not, follow the steps in “Install & Replace Battery” to insert the batteries.

2. Make sure that all connections are tight, the handles are in closed position. Turn on the water supply. Run water through the valve. Check for leakage. Repair as needed.

3. Test the product with water
Open all switch buttons and check that all functions operate properly. Verify each connection to ensure it is secure, and verify that the water flow is normal.


Return the valve to its original position and shut off the faucet.

温度测试与调整

温度测试前，应确保供水系统充分且有较高的温度。把手按钮垂直朝下时，打开龙头让水流出。进行温度测量，出厂时温度设定在36~38°C范围内。如超出这个范围，要进行调整。调整步骤如下：

取下把手盖，用螺丝刀取下螺钉和温控把手组件。

在正常水流状态下，由冷水位置开始慢慢转动温控阀轴(保持同一方向)直至获得37°C水流。如果温度超过37°C，回到冷水位置重新调整。温度稳定后，不要转动温控阀轴。安装温控把手，使温控把手按钮垂直朝下(装配后不按按钮时不能逆时针转动)。锁紧螺钉，安装把手盖。



Verification and Setting

Ensure that the water feeds of the faucet have reach the highest temperature by running the water sufficiently. When the button on the temperature handle is downward vertically, the water temperature should be within a range of 36°C and 38°C, as measured by a thermometer. If not, the installer can adjust the setting. Proceed with the setting as follows:

Remove the cover. Take out the screw with screw driver to uninstall the temperature handle.

Under the normal condition of water flow, slowly turn the temperature selector (Always in the same direction) from the cold water position until water temperature reaches 37°C. If the temperature goes over 37°C, go back to the “cold” setting and reset it. When the temperature is stable, do not turn the cartridge spindle. Install the temperature handle. Ensure the button on the temperature handle is downward vertically(After assemble, it can not be turned counter-clockwise if not pushing the button). Tighten the screw. Install the cover.