

交流电源盒(6V) AC POWER UNIT(6V)

安装说明书 INSTALLATION INSTRUCTIONS K-26845T-NA

BEFORE YOU BEGIN

- Please read these instructions carefully to familiarize yourself with the required tools, materials, and installation sequences. Follow the sections that pertain to your particular installation. This will help you avoid costly mistakes. In addition to proper installation, read all operating and safety instructions.
- All information in these instructions is based upon the latest product information available at the time of publication. Kohler China reserves the right to make changes in product characteristics, packaging, or availability at any time without notice.
- These instructions contain important care, cleaning, and warranty information-please leave instructions for the consumer.

安装之前

- 请通读本说明书,以便了解所需工具、材料及安装程序。 请遵照相关章节进行安装,以避免由于安装不当而导致不 必要的损失。除了有关正确的安装方法之外,还务请详阅 所有操作安全说明。
- 本说明书所含一切资料,均以印刷时所有的最新产品为准。科勒中国保留随时更改产品特性、包装或供应情况的权利,恕不另行通知。
- 本说明书包含了有关护理、清洁及保养等重要资料-请交予 用户保存。

TOOLS AND MATERIALS


- Tape measure
- · Connection wires (not supplied)
- Wire-cutter
- · Insulating tape
- Screw driver

所需工具及材料

- 卷尺
- 连接线(用户自备)
- 剥线器
- 绝缘胶布
- 十字螺丝刀

PRODUCT REQUIREMENTS

- 1. Electrical requirement: K-26845T-NA Input AC 220-230V, Frequency 50/60 Hz; Output DC 6V; Output power < 1W.
- 产品规格
- 电气规格: K-26845T-NA输入AC 220-230V, 频率50/60 Hz; 输出 DC 6V;输出功率小于1W.
- 2. Dimension requirement: L \times W \times H=72mm \times 55mm \times 27mm.
- 2. 尺寸规格:长×宽×高=72mm×55mm×27mm。




Note: One AC power unit can only supply one sensor.

注意: 一个交流电源盒组件只能供一个感应器

科勒(中国)投资有限公司 中国上海市静安区江场三路158号 邮编:200436 制造商:上海科勒电子科技有限公司 中国上海市宝山区丰翔路1955号 邮编:200444

安装说明




Note:The DC connector is forbidden to be connected to AC 220-230V。 注意: 禁止将交流AC220-230V接入DC接线端。

Do not connect to power supply while installing. Connection wire is not supplied. AC connection wire with insulating sleeving is recommended. Wire of which the nominal section area of conductor is not less than 0.5mm² is also recommended. DC connection use wire of which the nominal section area is not less than 0.3mm². Please cut the wire according to actual installation requirements(The length of cut wire is recommended less than 10m). Please implement the connection in exact accordance with the picture below.

安装时不要向电源盒供电,连接线请用户自备。建议交流连接线采用带绝缘和护套层的电线,导体标称截面积≥0.5mm²的电线; 直流连接线采用导体标称截面积≥0.3mm²的电线,其长度根据实际安装需要自行裁剪(建议裁剪电线长度<10m)。请严格按照下图进行连接。

1. The assembly drawing for AC power unit and sensor faucet

1.交流电源盒配感应龙头装配图




Note: The AC power unit is installed in control valve box.

备注: 交流电源盒组件被安装在控制阀组件内

2. AC power unit installed in control valve box

2.交流电源盒安装在控制阀盒内时

(1).Unscrew the screw(1) on valve box cover(2),then tearing down valve box cover.




(1). 用螺丝刀拧松阀盒盖(2)上的螺钉(1), 拆卸阀盒盖(2)。

(2). Connecting the connector from AC power unit with power wire assembly in electrical control box.



(2).对照图示的接线图,将交流电源 盒的接线端与电控盒上的电源线接 线端相连接。


(3). Place the AC power unit and cabling, then fixing the valve box cover by screwing.



(3).放置好交流电源盒并理好线,最后装上阀盒盖并锁紧螺丝。

Note: ① is the outlet of AC power supply. Remove the clip (lamellar) during the process of use to ensure the smoothing of outlet.

② is the outlet of faucet sensor.



注: ①为交流电源出线口使用时, 将①的卡扣(薄片状)去除,保证出线口光滑。

②为龙头感应器出线口。

IMPORTANT CONSUMER INFORMATION 用户须知

- 1. All installation staff should be well familiar with installation instruction.
- When using products with AC power supply, you must connect wire in exact accordance with installation instructions.
- 3. When AC power unit is connected to 220-230V power resource, corresponding protective measures should be taken.
- 4. Please confirm no water penetration at the connection area of AC wiring, and the connection area is not easy to be affected by damp.
- 5. Don't connect power unit to AC power supply until the sensor installation is finished.
- The head AC power supply must be protected with appropriate fuse.
- Please confirm the AC power supply and water supply should be shut off before maintaining the products with AC power related.
- 8. All electrical connection must be compliance with related regulation and codes.
- 9. Different types of power unit match with different sensors. please read sensor installation instruction carefully.

- 1. 所有参与安装人员都必须熟知安装说明。
- 2. 使用交流供电型产品时,务必按照说明书的要求正确连接电线。
- 3. 将交流电源盒接入220-230V电源时,应采取相应的防护措施。
- 4. 应确保交流电线连接处无水渗入以及不易受潮。
- 5. 务必在感应器安装完毕后,才向交流电源盒供电。
- 6. 交流电的总电源必须有合适的熔断丝加以保护。
- 7. 维修交流供电型的产品时,必须首先断开交流电源并关闭水源。
- 8. 所有电路连接必须符合相关规范和条例要求。
- 9. 不同型号的电源盒所配感应器不同,请详细阅读感应器产品说明书。

产品中有害物质含量的说明

回收提示

本产品超过使用期限或经过维修无法正常使用后,不应随意丢弃,请交由有废弃电器电子产品处理资质的企业处理,正确的处理方法请查阅国家或当地有关废旧电器电子产品处理的规定。

有害物质统计表

	有害物质名称							
部件名称	铅(Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)		
外壳组件	×	0	0	0	0	0		
阀体组件	×	0	0	0	0	0		
控制盒组件	×	0	0	\circ	0	0		
*电池盒组件	0	0	0	\circ	0	0		
*电池	0	0	0	\circ	0	0		
*交流电源盒		0	\circ	\bigcirc	0	0		
*进水组件	×	0	0	0	0	0		
附件类			0	0				

- ○:表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572现行有效版本规定的限量要求以下。
- × :表示有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572现行有效版本规定的限量要求。
- * :表示部分机型含有该部件。

注:本表格提供的信息是基于供应商提供的数据及科勒公司的检测结果。本产品应用环保设计理念,在当前技术水平下,所有有害物质或元素的使用已经控制到了最低程度,科勒公司会继续努力通过改善现有技术来减少这些物质的使用。



本产品的"环保使用期限"为10年,科勒公司根据产品设计特性指定该期限。只有在本产品使用说明书所述的正常情况下使用本产品时,"环保使用期限"才有效。

Description of Content of Hazardous Substances in Product

Reclaim Indication

When the product exceeds service life or is unable to use after repair, do not throw the product away in the normal trash. Please dispose the waste electronic parts through a qualified reclamation enterprise. Make sure the product is handled properly. Disposing of product must be done in accordance with the local or national government law.

Statistics of Contents of Toxic or Hazardous Substances or Elements

	Toxic or Hazardous Substance or Elements								
Part name	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr(VI))	Polybrominated biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)			
Cover Assy.	×	0	0	0	0	0			
Valve Assy.	×	0	0	0	0	0			
Control Box Assy.	×	0	0	\circ	0	0			
* Battery Box Assy.	\bigcirc	0	\circ	\bigcirc	0	\circ			
* Battery	\bigcirc	\circ	\circ	\circ	0	0			
* AC Power Box	\bigcirc	\bigcirc	\bigcirc	\circ	0	0			
* Water Inlet Assy.	×	0	0	0		0			
Accessories	0	0	0	0		0			

- : Indicates that the substance in the material composition is below the high limits of the current requirements in GB/T26572.
- $_{ imes}$: Indicates that at least one of the homogeneous substance in the material composition is below the high limits of the current requirements in GB/T 26572.
- * : Indicate only partial product series contains this substance.

Note: the information provided is based on the supplier data and Kohler inspection results. The product is designed not to hurt the environment. Under current technology, all hazardous materials have been used in the smallest amounts possible. Kohler will strive to reduce the use of these hazardous materials used in this product.



The product "service life for environment protection" is 10 years; Kohler Company will specify product service life based on product characteristics. The product "service life for environment protection" is only effective when the product is used as described in the product specification.