KOHLER。 USE & CARE 使用及保养

PLEASE SAVE THIS DOCUMENT FOR THE HOMEOWNER. 用户请妥善保存本标签。

Treat your decorative product just as you would treat your fine china. The best way to clean it is to use warm water and pat dry with a cotton cloth or soft sponge. **DO NOT** use bristle brushes or abrasive-backed sponges. They will scratch the decorative surface.

For occasional cleaning of stubborn deposits, use ONLY neutral cleaners: Apply the cleaner, wipe gently, and **rinse off any residue immediately.** Pat the product dry or wipe gently with cotton cloth.

• Always test your cleaning solution on an inconspicuous area before applying to a widespread surface.

请您像珍惜您的珍贵瓷器一样对待您的艺术系列产品,最佳清洗方式为使用温水擦洗,然后用棉布或软海绵轻轻拍干。**请勿**使用粗硬的刷子或带刮擦面的海绵,以免划 伤装饰表面。

对于顽固污渍,仅可使用中性清洁剂,使用方法如下:涂上清洁剂,轻轻擦拭,**立即 漂去残液**。使用棉布将产品拍干或擦干。

• 大面积使用清洁剂之前,请先在产品不起眼处局部试用。