


**99874T-B9 缸边式恒温浴缸花洒龙头**



\*\*订购时请说明颜色编号

**\*\*Color code must be specified when ordering**

**99874T-B9** 缸边式恒温浴缸花洒龙头

安装之前

## **BEFORE YOU BEGIN**

所有的资料是按最新出版的产品资料编写而成。科勒公司保留任何时候不经通知即可改变产品特性、包装或产品可供类型的权利。

说明书包括重要的安装、保养及清洁方面的内容，请把这些资料交给用户阅读。

### 注意事项:

1. 最小供水压力: 0.5bar(0.05MPa)。
  2. 推荐冷热供水压力: 3bar(0.3MPa)。
  3. 如果供水压力大于5bar(0.5MPa), 安装减压阀。
  4. 冷热供水的压力差不大于2bar(0.2MPa)。
  5. 热供水温度最低: 50°C; 最高: 70°C。
  6. 推荐的热供水温度: 60°C。
  7. 温度调整的基本范围为: 20°C到49°C。
  8. 安全限位温度: 37°C。


All information is based on the latest product information available at the time of publication. Kohler Co. reserves the right to make changes in product characteristics, packaging, or availability at any time without notice. Please leave these instructions for the consumer. They contain important information.

## **NOTES:**

1. Minimum supply pressures: 0.5bar.
  2. Recommended supply pressures: 3bar on hot and cold water.
  3. If supply pressure higher than 5bar: install a pressure reducer.
  4. Pressure difference between hot and cold supply: 2bar maximum.
  5. Hot supply water temperatures, minimum: 50°C, maximum: 70°C.
  6. Recommended hot supply water temperature: 60°C (energy-saving).
  7. Setting range, approximately: 20°C to 49°C.
  8. Safety stop at: 37°C.


安装尺寸

## **ROUGH-IN DIMENSIONS**



## 安装步骤

## INSTALLATION



### 如何安装阀体组件


尽可能在安装浴缸之前安装水龙头。安装之前一定要先彻底冲洗供水管以清除管道中的杂质。

在浴缸边缘合适位置根据尺寸打孔。

### How to Install the Valve Assy

If possible, install this faucet before installing bath tub. Flush the water supply pipes thoroughly to remove debris.


Drill holes according to the dimensions at the correcting position of the tub fringe.



将基座(1)对齐浴缸的孔放置好。

将恒温阀组件(2)从浴缸台面底部插入孔中，“H”在左边，进水端止逆阀组件(3,4)在对应的孔中。

用上方的螺母(6)锁紧恒温阀芯组，下方用安装组件(5)固定。



Put the base plate(1) onto the deck.

Insert the temperature valve assembly(2) into the mounting hole from underside of the tub. The check valve assy(3,4) with mark “H” should be on the left.

Tighten the nut(6), install the fixture kit(5).

# KOHLER®

## SERVICE PARTS


### 零件图

### Deck Mount Thermostatic Bath Shower Faucet

曼达

BEITOU


**99874T-B9 缸边式恒温浴缸花洒龙头**



\*\*订购时请说明颜色编号：

注意：除中国外，其他亚太区订购服务零件时请在前面加SP(即SPXXXXXX\*\*)。





## 如何连接出水口

将出水口组件(32)装到浴缸上，从下方装入垫片(29)和钢圈(30)，用螺母(31)锁紧。

**注意：**若供水压力偏高，可安装限流器(38)到出水口组件内。

## 如何连接软管

恒温阀组件上的软管(33、34)分别与冷热水源连接。带“H”标记一侧连接的软管(34)接热水。

切换阀上的软管(35)连接出水口组件。

软管(36)连接切换阀和花洒软管。

软管(37)连接恒温阀和切换阀。

## How to Install the Spout

Insert the spout assembly(32) into the hole of tub. From underside of the tub, fit the washer(29) and steel washer(30). Tighten the spout assembly by nut(31).

**NOTE:** If water pressure is too high, restrictor(38) could be installed into the spout assembly.

## How to Connect the Hoses

Connect the hoses(33, 34) on the temperature valve assy to cold and hot water supplies respectively. Connect the hose(34) with the “H” mark to hot supply.


Connect the hose(35) on the diverter valve assy to spout assembly.

Connect the diverter valve assy and shower hose by the hose(36).

Connect the diverter valve assy and temperature valve assy by hose(37).

## 安装结果检查

## INSTALLATION CHECKOUT



检查并确保所有的衔接处都已拧紧，确保切换把手(16)在关的位置。

打开排水系统和主要供水源。检查并修理有漏水的接口。

取下花洒(11)，旋转切换把手至手持花洒标志，让水流出约一分钟以清除杂质。旋转切换把手至出水口，同样让水流出一分钟以清除杂质。关闭水龙头并装回花洒。

Ensure that all connections are tight. Ensure that the diverter handle(16) is in the off position.

Turn on the main water supply and drain. Check for leaks, repair as needed.

Remove handshower(11), turn the mark in diverter handle to handshower indication. Run water through the hose to remove any debris. Turn the mark to spout indication. Run water to remove any debris. Turn off the faucet, reinstall the handshower.

## 使用说明

旋转切换把手选择出水口出水或花洒出水。

慢慢旋转温控把手即右把手，顺时针旋转调低水温；逆时针旋转调高水温；把手上有两个安全限位，如想得到更高的温度，按住按钮继续旋转。

按动花洒面板上的按键即可切换花洒的各种功能。

## 清洗说明

适用于所有加工处理过的表面：以中性肥皂水清洗镀层表面，再以干净的软布彻底擦干整个表面，许多清洁剂，比如氨水、去污粉及洁厕灵等，会对电镀表面造成伤害，切忌使用。

有磨损性的清洁用具或清洁剂也不可使用于科勒牌的水龙头及其配件上。

## HANDLE OPERATION

Turn the diverter handle to choose the spout or handshower model.

The temperature is set by slowly turning the temperature selector(right-hand handle). Turn it clockwise for lower temperature; Turn it counter-clockwise for higher temperature. For safety reason, there is a stop to limits temperature. To get a higher temperature, push the button and continue turn the temperature selector.

Press the buttons of the handshower to change the water flow.

## CLEANING INSTRUCTIONS

All Finishes: Clean the finish with mild soap and warm water. Wipe entire surface completely dry with clean soft cloth. Many cleaners may contain chemicals, such as ammonia, chlorine, toilet cleaner etc. which could adversely affect the finish and are not recommended for cleaning.

Do not use abrasive cleaners or solvents on Kohler faucets and fittings.