



Features

- 27" (686 mm) minimum base cabinet width
- Single bowl
- 9" (229 mm) depth provides generous workspace
- Bowl slopes toward drain to minimize water pooling
- Offset drain increases workspace in the sink and storage space underneath
- Includes stainless steel sink rack
- Small size fits compact spaces
- Three faucet holes and one accessory hole to the right



KOHLER® enameled cast iron

Installation

Top-mount

Recommended Products/Accessories

K-8801 Sink drain and strainer with tailpiece

K-8799 Sink drain and strainer basket

K-23726 Drain treatment

K-23725 Cast iron cleaner

1411886 Undermount sink kit 23"

K-35000 Three-piece workstation sink accessory set

K-35001 Maple wood cutting board

K-35002 Ice bucket holder

K-35003 Workstation sink cover

K-35005 Marble serving tray

K-35487 Three-piece ice bucket set

K-35484 Three-piece workstation sink prep bowl set

Optional Products/Accessories

K-11352 Disposal Flange with Stopper

K-9000 P-Trap

Included Components

K-6238 Sink Rack



Codes/Standards

ASME A112.19.1/CSA B45.2 IAPMO Certification

KOHLER® Enameled Cast Iron Kitchen and Bathroom Sink Lifetime Limited Warranty

See website for detailed warranty information.

Available Colors/Finishes


Color tiles intended for reference only.

Color	Code	Description
	0	White
	FF	Sea Salt™
	96	Biscuit
	95	Ice™ Grey
	7	Black Black™





Riverby® 25" top-mount single-bowl kitchen sink K-5872-4A1



Technical Information

All product dimensions are nominal.

Basin configuration: Single Bowl

Center(s):

Min. base cabinet 25" (635 mm)

width:

Bowl area (Only): Length: 22-1/4" (565 mm)

Width: 15-13/16" (402 mm) Bowl depth: 9" (229 mm)

Number of deck

holes:

Faucet hole spacing: 4" (102 mm)
Faucet hole(s): 1-3/8" (35 mm)
Drain hole: 3-7/8" (98 mm)

Template: 1172565-7, required, included

Notes

Install this product according to the installation instructions.

NOTICE: Countertop manufacturer or cutter must use the cut-out template provided with the product, or a current one provided by Kohler Co. (call 1-800-4-KOHLER). Kohler Co. is not responsible for cutout errors when the incorrect cut-out template is used.

IMPORTANT! Use of the colander, wood cutting board, and utility rack requires the "reveal" cutout option on the cutout template.

