



K-R31498

AC power adapter for touchless faucet

Features

- For use with KOHLER touchless kitchen faucets
- Eliminates the need for batteries
- Easily connects to power box for fast and simple installation
- 120 volt unswitched power source required



Available Colors/Finishes

Color tiles intended for reference only.

NA NA Not Applicable



1-800-4KOHLER (1-800-456-4537)
Kohler Co. reserves the right to make revisions without notice to product specifications.
For the most current specification sheet, go to www.kohler.com USA or www.kohler.ca Canada.
7-29-2026 23:36 - US-CA

THE BOLD LOOK
OF **KOHLER**

Codes/Standards

UL 1310
cUL Listed
UL Listed

Recommended Products/Accessories

K-R77748-SD Touchless pull-down kitchen sink faucet with
soap/lotion dispenser

K-R32323-SD Touchless pull-down kitchen faucet with
soap/lotion dispenser


K-REC32323-SD Touchless pull-down kitchen faucet with
soap/lotion dispenser

Warranty

See website for detailed warranty information.

KOHLER® One-Year Limited Warranty





Installation

- Intended for use in North American outlets only

Installation Notes

Install this product according to the installation instructions.

