


KOHLER<sup>®</sup>

INSTALLATION INSTRUCTIONS

安装说明书

Angle Valve

| R76389T-B9    R76390T-B9    角阀                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 安装之前                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | BEFORE YOU BEGIN                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <p>所有的资料是按最新出版的产品资料编写而成。科勒公司保留任何时候不经通知即可改变产品特性、包装或产品可供类型的权利。</p> <p>说明书包括重要的安装、保养及清洁方面的内容，请把这些资料交给用户阅读。</p> <p><b>注意事项：</b></p> <p>1. 一定要先彻底冲洗供水管以清除管道中的杂质。</p> <p>2. 使用静水压力不超过1.0MPa(10bar)，适用水温0°C~80°C。</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | <p>All information is based on the latest product information available at the time of publication. Kohler Co. reserves the right to make changes in product characteristics, packaging, or availability at any time without notice.</p> <p>Please leave these instructions for the consumer. They contain important information.</p> <p><b>NOTES:</b></p> <p>1. Flush the water supply pipes thoroughly to remove debris.</p> <p>2. The static water pressure should not exceed 1.0MPa(10bar). The supply water temperature should be between 0°C and 80°C.</p> |
| 使用说明                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | OPERATION INSTRUCTIONS                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| <p>顺时针旋转把手为关，逆时针为开。</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | <p>Turn the handle clockwise for closing, and turn counter-clockwise for opening.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 安装尺寸                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | ROUGH-IN DIMENSIONS                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <div><p>The technical drawing consists of two views of the angle valve. The left view is a front elevation showing a square body with rounded corners and a central handle. A dimension line above the body indicates a width of 55x55. The right view is a side elevation showing the valve's profile. It features an inlet port on the left labeled '进水 Inlet' and an outlet port on the right labeled '出水 Outlet'. The inlet port has a connection size of G1/2". The outlet port has a connection size of G1/2". The overall height of the valve body is 28.5. The distance from the center of the inlet port to the center of the outlet port is 39. The total width of the valve body is 76.</p></div> |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |

